



Installation guide for Chevrolet Camaro 70-81

- 1 Remove the ash tray from the dash.
The charger will locate snugly between the two posts and the front of the ashtray.



- 2 On the underside of the tray lay out the hole positions as shown. Then drill approximately $\frac{3}{32}$ " or 2.5mm clearance holes and countersink for the two 2mm screws.



- 3 Drill a $\frac{1}{4}$ " (6mm) hole for the wire exit hole at the back of the tray. Location isn't critical but the layout below works well.



- 4 Install the grommet. Hot water will help to soften it if needed. Slide the wire through the grommet and locate the charger as shown in picture 1
- 5 Hold the charger firmly in position and screw in the two self tapping screws into the charger. No drilling of the charger is necessary. A manual screwdriver is best with some pressure applied.



- 6 Prepare your power and ground wires behind the dash. Thread the charger wire through the grommet in the surround as you insert the ashtray into the surround. Check for smooth operation and then connect the wires. Leave a few inches of excess length to allow for the movement of the tray when opening.

- 7 Plug in your phone and go for a cruise!