



Installation guide for International Scout 71-80 and Truck 69-75

- 1 Remove the ash tray from the dash.
Then remove the center bar from the cigarette stubber as the mounting screw will pass through that spot. A pair of small wire cutters works well as the steel is very thin. The yellow line in the oval shape in the picture below shows the piece to remove.
- 2 Drill a ¼" (6mm) hole for the wire exit hole on the backside of the tray.
Location isn't critical but the layout in red below will do. Remove sharp edges. A larger drill bit works well for this.



- 3 Install the grommet. Hot water will help to soften it if needed. Slide the wire through the grommet and position the charger as shown below. Insert the metric screw through the stubber and tighten just enough to stop the charger from moving.



4 Prepare your power and ground wires behind the dash. Be sure to allow enough length to allow for the opening and closing of the ashtray.

Reinsert the tray into the dash.

5 Plug in your phone and go for a cruise!