



## 64-66 Ford Mustang USB charger install.

- 1 Remove ashtray from vehicle.**
- 2 Drill a 1/4" hole for the wire grommet in the back of the ashtray. Location isn't critical, but make sure it isn't too close to the edge and in a place where there is room for the wire to exit behind the dash. The location (red dot) in the following image is a suitable spot. Remove any sharp edges from the hole.**



- 3** Insert the grommet in the hole. Warming the grommet in hot water will soften it for an easier install.
- 4** Remove the socket hex screw from the charger.
- 5** Poke the wire through the grommet from the inside. Position the charger as shown below then insert the screw through the hole in the stubber just tight enough to stop it moving, but not too tight.



- 6 Insert your ashtray into the dash (not shown) with the power wire going in first. Disconnect the battery, then connect your wires with your preferred method. Red to power and black to ground. A soldered joint is best, but a crimped connection will be adequate. Remember to leave some slack in the wire to allow for the movement of the ashtray.**



- 6 Check the ashtray opens and closes correctly, reconnect the battery and go for a cruise.**