



66-67 Chevrolet Nova USB charger install.

- 1 Remove the ashtray from the vehicle and clean out all the ash.
- 2 Drill a 1/4" hole for the wire grommet in the ashtray base. Location isn't critical. The image below shows a suitable spot.



- 3 Remove any sharp edges on the hole with a deburring tool or larger drill bit. Insert the supplied grommet. (Softening it in hot water will make it easier.)**

- 4 Remove the socket hex screw from the charger. Poke the wire through the grommet, then position the charger as in the image so the screw hole lines up. Once aligned insert the supplied socket head screw just tight enough to stop it moving, but not too tight. The wire should run down the inside edge of the ashtray, take care not to trap it.**



- 5 Connect your wires with your preferred method (a soldered joint is best, but crimp terminals will work.) Leave some slack to allow for the opening and closing of the ashtray.**

- 6 Take a pic or two of your completed installation and send it to us if you can, plug in your phone and go for a cruise.**